

Laboratory # 7

Hand Gesture Recognition Using Leap Motion and Deep Learning

1 Introduction

In this exercise, we will use a USB-connected sensor called Leap Motion. It detects a moving object in close proximity (1–20cm) by using the time-of-flight principle; in this sensor, near-infrared beams are sent and received to detect the distance to the object's surface, and, therefore, recover the object's shape and position (same as Kinect camera). The purpose of this lab exercise is to apply the concepts of machine learning to **recognize gestures** performed by a hand, such as a circle and a swipe in the air, based on the coordinates of the hands' joints identified by the Leap Motion device.

There are two options to get data for this Lab: you can collect your data using the Leap Motion provided in the lab, or use the data pre-recorded and available on D2L. To collect the data from the Leap Motion, you will need to set up an environment based on Python 2 version, explained in Section 1.2. If you prefer to use the data provided, you can skip this step.

The classification will be performed using Python 3 and Keras library¹. The classifier used is the *Long Short-term Memory* (LSTM), a deep learning model for time-series analysis. Section 1.3 will explain how to create a new Python 3 environment only for this purpose.

1.1 Installation of Leap Motion driver

The UltraLeap (the company that developed the Leap Motion) created SDKs for various programming languages but each SDK (Software Development Kit) is provided by its version of the framework library². The most up-to-date version for Python is *Leap Motion Orion 3.2.1*. By default, this version works only with Python 2.7

NOTE: you might be able to generate and compile your version of the “LeapPython” source code with SWIG interface file (it is a tool that connects programs written in *C* and *C++* to Python) that is provided in the SDK. This compiling process is out of the scope of this Lab Project.

To set up the Leap Motion driver on Windows to collect data, you will need to follow the steps below:

1. Download the .zip file the *Leap Motion Orion 3.2.1* SDK from D2L.
2. The zip-file you downloaded contains the folder *LeapSDK*. You need to copy the following files to the same folder of your project's code:

```
LeapSDK/lib/Leap.py  
LeapSDK/lib/x64/LeapPython.pyd  
LeapSDK/lib/x64/Leap.dll
```

In Section 1.2, we explain how to install Python 2 using your current Anaconda installation. After that, you will be able to collect the data.

¹<https://keras.io/>

²<https://developer-archive.leapmotion.com/documentation/python/index.html>

1.2 Creating Python 2 environment

Anaconda offers the possibility of creating “environments”³. An environment plays the role of a container where you can install a different Python version with another set of libraries. By default, the Anaconda installation creates the “base” environment; it is shown in the first line when you open the *Anaconda Powershell Prompt*. You can create your environments regardless of the Python version.

For the data collection, you need to create a Python 2 environment. With the *Anaconda Powershell Prompt* opened, follow the instructions:

1. Create a Python 2 environment named “py2”:

```
conda create -n py2 python=2.7
```

2. Activate the created environment:

```
conda activate py2
```

3. In this new environment (py2), install the Spyder editor along with some other libraries:

```
conda install spyder numpy pandas notebook
```

After these steps, on your Anaconda’s entry on the Start menu, you will see a new Spyder and Jupyter Notebook entries called “Spyder (py2)” and “Jupyter Notebook (py2)”, respectively. This is the Spyder version that you need to run when Python 2 is required.

1.3 Installation of the Keras library

The machine learning technique used in this lab is a deep neural network with memory, called Long-Short-Term-Memory (LSTM). This is needed to recognize gesture performed in time. The LSTM network uses the Keras library (Python 3), which is not included in your default Anaconda installation. For the Keras installation, we recommend the creation of a new environment to avoid the conflict with other libraries.

Open Anaconda Powershell Prompt and follow the steps below:

1. Create a new environment called leapmotionNN:

```
conda create -n leapmotionNN python=3.9
```

2. Activate the new environment:

```
conda activate leapmotionNN
```

3. Install the necessary libraries, including Keras and Tensorflow:

```
conda install -c conda-forge keras tensorflow jupyter opencv pandas scikit-learn  
matplotlib notebook
```

³<https://docs.conda.io/projects/conda/en/latest/user-guide/tasks/manage-environments.html?highlight=environment>

After running these commands, a new Jupyter Notebook entry will appear on your start menu; it corresponds to the new environment: Jupyter Notebook (leapmotionNN). You can run the LSTM in it.

2 The laboratory procedure

2.1 Data collection

With the Leap Motion already connected to your computer, open Spyder (for Python 2), then open the sample code `LeapMotion_Recorder.py`. When you run it, you'll be able to collect the data captured by the Leap Motion. When you finish performing a gesture, press [ENTER] in the Python terminal, to save your data in the file `data1.csv`.

Repeat this process 10 – 20 times to record several samples of the same gesture. For each gesture you will have a `.csv` file.

3 Procedure

All the steps described below are required to be done using Python 3. Note that Python 2 was used *only* to collect the data.

3.1 Data preparation and classification with LSTM

To train a classifier to distinguish between two gestures, you will need to collect data from the same subject performing both sets of gestures. Consider one gesture to draw a circle in the air, another one as drawing a line (a swipe). Once you have defined the gestures you want to collect, perform the same gesture 10 to 20 times.

All the data must to be saved in `.csv` files. We recommend that you saved one file per gesture. For example, the piece of code below shows the names of 20 files (10 drawing of a circle and 10 swipe movements) stored in two variables to be used in the training step:

```
circle = ['circle1.csv', 'circle2.csv', 'circle3.csv', 'circle4.csv', 'circle5.csv',  
          'circle6.csv', 'circle7.csv', 'circle8.csv', 'circle9.csv', 'circle10.csv']  
  
swipe = ['swipe1.csv', 'swipe2.csv', 'swipe3.csv', 'swipe4.csv', 'swipe5.csv',  
         'swipe6.csv', 'swipe7.csv', 'swipe8.csv', 'swipe9.csv', 'swipe10.csv']
```

3.1.1 Preparing the data

Put all your `.csv` files in the folder `data/`. Instead of manually typing the name for each file, use the Python resource called *list comprehension* to recover all the file names:

```
# the directory where your data is  
mypath = './data'  
  
# creating a list with all the filenames  
datafiles = [f for f in listdir('data') if isfile(join(mypath, f))]
```

All the data in .csv files are stored as Pandas' DataFrames⁴ for easy recovery when necessary.

Before defining a DataFrame, we need to define the columns' names; those names correspond to the features captured by the Leap Motion. Check Leap Motion's web page to see which features can be recorded⁵. The following code defines all the columns' names necessary:

```
columns = ['handPalmPosition_X', 'handPalmPosition_Y', 'handPalmPosition_Z',
           'pitch', 'roll', 'yaw', 'GestureTypeCircle', 'GestureTypeSwipe',
           'wristPosition_X', 'wristPosition_Y', 'wristPosition_Z',
           'elbowPosition_X', 'elbowPosition_Y', 'elbowPosition_Z']

# fingers used to perform the gesture
finger_names = ['Thumb', 'Index', 'Middle', 'Ring', 'Pinky']
# fingers' bones identified by Leap Motion
bone_names = ['Metacarpal', 'Proximal', 'Intermediate', 'Distal']

for finger in finger_names:
    columns.append(finger + 'Length')
    columns.append(finger + 'Width')

# for each finger several features are collected
for finger in finger_names:
    for bone in bone_names:
        columns.append(finger + bone + 'Start_X')
        columns.append(finger + bone + 'Start_Y')
        columns.append(finger + bone + 'Start_Z')
        columns.append(finger + bone + 'End_X')
        columns.append(finger + bone + 'End_Y')
        columns.append(finger + bone + 'End_Z')
        columns.append(finger + bone + 'Direction_X')
        columns.append(finger + bone + 'Direction_Y')
        columns.append(finger + bone + 'Direction_Z')
```

Now load the data. The file names, previously defined when collecting the data, indicate which gesture is described in that specific .csv file. This gesture corresponds to the class we wish to classify.

The code below has all the features as a list stored in the variable x (where each element is a DataFrame), and the corresponding class is contained in the variable y:

```
# Features
x = []
# Labels
y = []

for sample in datafiles:
    relative_path = 'data\\' + sample
    tmp = pd.read_csv(relative_path, usecols=columns)
```

⁴<https://pandas.pydata.org/pandas-docs/stable/reference/api/pandas.DataFrame.html>

⁵<https://developer-archive.leapmotion.com/documentation/python/index.html>

```
# Normalize the sample size: LSTM requires all inputs to be the same size!
print('{}\nsize raw = {}'.format(relative_path,tmp.shape))
while tmp.shape[0] < NUMBER_TIMESTEPS:
    tmp = tmp.append(pd.Series(0, index=tmp.columns), ignore_index=True)

if tmp.shape[0] > NUMBER_TIMESTEPS:
    tmp = tmp.head(100)
print('size normalized = ',tmp.shape)

tmp_x = tmp[[column for column in list(tmp.columns)
              if column != 'GestureTypeCircle'
              and column != 'GestureTypeSwipe']]
tmp_y = tmp[['GestureTypeCircle', 'GestureTypeSwipe']]

x.append(tmp_x)
y.append(tmp_y)
```

The last step when preparing your data is to divide it into two sets, one for training and one for testing. This is done using Scikit-Learn's function `train_test_split(...)`. Besides the variables `x` and `y`, we have to define the proportion of the test set. In the example below, the test size corresponds to 30% of all data:

```
# Set a percentage of test set fraction
test_size = 0.3 # 30%

# Divide data into train and test sets
X_train, X_test, y_train, y_test = train_test_split(x, y,
                                                    test_size=test_size,
                                                    shuffle=True)

# Turn list(DataFrame) into numpy.ndarray
X_train = np.array(X_train)
X_test = np.array(X_test)
```

At this point, we have our data split into four variables: `X_train`, `X_test`, `y_train` and `y_test`. The variables `X_...` are the features, while the `y_...` are the corresponding labels.

3.2 Classification

To perform the classification of gestures, use the file `Lab07-LeapMotion-GestureClassifier.ipynb` as a template. Since the gesture is represented as a time-series, the hand joint coordinates change over time. Thus, the classifier should deal with such data. In this example, we will use the type of a neural network called *Long Short-term Memory* (LSTM) available in the Keras library.

3.2.1 Creating an LSTM in Keras

After preparing the data in matrices, two pieces of information are essential: the size of the input data and the size of the network output. Note that we use a one-hot encoding for the classes (a code

that has one '1' and the rest are 0's). For the case of 2 classes, our network should have at least 2 outputs, one for each class. It can be defined manually or recovered from other variables such as shown below:

```
# the number of features (from the data)
NUMBER_FEATURES = 202
```

```
# the number of classes/gestures
NUMBER_OUTPUTS = 2
```

The `Sequential()` class will be used to create an empty model. Next, the LSTM and network layers (`Dense`) are added, followed by defining the *Rectified Linear Unit - ReLu* activation function.

The model is consolidated when you call the function `compile(...)`. This is where you also set the optimizer, and the metric to be evaluated during the training, among various other parameters⁶. The code below shows a function defined to facilitate the model creation:

```
def build_model():
    model = models.Sequential()

    # the input layer expects:
    # 1 or more samples, NUMBER_Timesteps time steps and NUMBER_FEATURES features.

    # 1st LSTM layer with 256 units
    model.add(layers.LSTM(256, return_sequences=True,
                          input_shape=(NUMBER_Timesteps, NUMBER_FEATURES)))

    # 2nd LSTM layer with 256 units
    model.add(layers.LSTM(256,
                          input_shape=(NUMBER_Timesteps, NUMBER_FEATURES)))

    # Hidden fully connected layers of the neural network
    # 512 neurons
    model.add(layers.Dense(512, activation='relu'))
    model.add(layers.Dropout(0.5))
    # 256 neurons
    model.add(layers.Dense(256, activation='relu'))
    model.add(layers.Dropout(0.5))
    # 512 neurons
    model.add(layers.Dense(512, activation='relu'))

    # Classification layer of the neural network
    model.add(layers.Dense(NUMBER_OUTPUTS, activation='softmax'))

    opt = Adam(learning_rate=0.002)
    model.compile(loss='categorical_crossentropy',
                  optimizer=opt,
                  metrics=['accuracy'])
```

⁶https://keras.io/api/models/model_training_apis/

```
# this shows the network structure
```

```
model.summary()
```

```
return model
```

To train the model, the `fit(...)` function is called along with the training set, the respective labels, the batch size (the number of samples used to each training step) and the number of epochs. Below, we train the model using 10 epochs and the batch size equals to the training set size:

```
model.fit(X_train, y_train, epochs=10, batch_size=len_train)
```

When the model is trained, you can use the test set to evaluate the generalization performance. For this, the function `evaluate(...)` is used with the arguments corresponding to the test set (samples and labels):

```
test_loss, test_acc = model.evaluate(X_test, y_test)
```

To recover the predicted class of each sample from the test set, you can use the `predict(...)` function:

```
# testing the classifier trained with the test set
```

```
y_pred = model.predict(X_test)
```

```
matches = (y_pred == y_test)
```

```
print('Total of matches: %d' % (matches.sum()))
```

```
match_rate = matches.sum() / float(len(matches))
```

```
print('Match rate: %.2f' % (match_rate))
```

The evaluation of the classifier after the training is an important step in your machine learning pipeline. To do so, use the code to create a confusion matrix and the classifier evaluation approach similar to the one used in Lab # 6.

4 Lab Report

Your report in the form of a Jupyter Notebook/Python (file extension `.ipynb`) shall include the following graded components (10 marks total):

- Introduction (a paragraph about the purpose of the lab, 0.5 marks).
- Description of the result on each exercise with illustrations/graphs and analysis of the results (9 marks are distributed as shown in the Exercise section).
- Conclusion (a paragraph on what is the main take-out of the lab, 0.5 marks).

Save your Notebook using menu “Download As” as `.ipynb`, and submit to D2L dropbox for Lab 7 by the end of the day of the following Thursday.

5 Lab Exercise in Jupyter Notebook with Python

For the following exercises, use the sample data available on D2L, or your own data.

- **Exercise 1** (3 marks): Consider 60% of samples per gesture for training and 40% for testing. Perform the classifier evaluation for this case. Next, use 80% of samples per gesture for training and 20% for testing. Perform the classifier evaluation and compare it against the first case (60 and 40%).
- **Exercise 2** (3 marks): Consider two different numbers of nodes in the LSTM layers (for example, 128 instead of 256). Perform the classifier evaluation and compare your two choices of the node numbers.
- **Exercise 3** (3 marks): Consider the dropout probability. In the code, it is set to 0.5. Change it to another value. Perform the classifier evaluation and compare it against the first case (60 and 40%).

6 Acknowledgments

We would like to thank the TA Illia Yankovyi for developing and testing the code used in this laboratory.

March 3, 2023